

Roller Cover Bracket Installation Guide

Tools Required

- 4mm Drill Bit
- 5/16" Hex Head Bit
- Power Drill
- Marker

Installation Instructions

Step 1 – Position the Bracket

Align the roller cover bracket on the cabinet strip in its desired position.

Using a marker, mark the four mounting holes to indicate where the bracket will be secured.



Step 2 – Remove the Cabinet Door & Pre-Drill

Before drilling, remove the cabinet door to ensure you can clearly see and access the steel frame behind the cabinet strip.

Using a 4mm drill bit, pre-drill the four marked holes through the cabinet strip.

Important: Ensure the holes are positioned so the fixing screws will secure directly into the steel frame.



Step 3 – Secure the Bracket

Position the bracket against the cabinet strip, ensuring it sits flush and level.

Using the 5/16" hex head bit, install the:

- Top right screw first
- Bottom screw second

This will hold the bracket firmly in place and allow you to confirm alignment before installing the remaining fixings.

Important: Verify the screws are engaging with the steel frame and not just the cabinet panel.



Step 4 – Install Remaining Screws

Once the bracket is correctly aligned, install the remaining screws and tighten all fixings securely.

Do not overtighten, as this may damage the cabinet strip.



Step 5 – Install Second Bracket

Repeat Steps 1–4 on the opposite side of the spa to install the second bracket.